

# PARTS LIST FOR FVO-1000TR

## HEATER PART LIST

Part Number	Part Description
FV-401TR	PRIMARY FAN MOTOR - 1 1/2 H.P.
FV-402TR	16" FAN BLADE
FV-404TR	18" POWER CORD C/W PLUG END
FV-405	SS HEAT EXCHANGER
40-113-D7GALV	1/2" X 7" GALVANIZED NIPPLE
40-108-8GALV	1/2" GALVANIZED CAP
FV-406	HIGH LIMIT SWITCH (250F OUTLET)
FV-407A	FAN LIMIT SWITCH (ADJUSTABLE)
FV-407G	FAN LIMIT SILICONE GASKET
FV-408	FAN MOTOR CANOPY C/W LABELS
FV-409TR	TOGGLE SWITCH (ON CONTROL BOX)
FV-410	GREEN LIGHT (ON CONTROL BOX)
FV-411	RED LIGHT (ON CONTROL BOX)
FV-414B	THERMOSTAT PLUG (ON CONTROL BOX) 2011>
FV-415A	MALE CONNECTOR FOR FV-THB
FVO-415	RIELLO BURNER (OIL)
FVO-416ATRTC	300 US GALLON STEEL OIL TANK (FVO-1000TR) TC APPROVED
FVO-416FITR	FUEL FILL INLET FOR STEEL TANK
FVO-416AGTR	FUEL GAUGE (POLY TANK) INCLUDES GASKET & SCREWS
FVO-417TR-1	CAP FOR FUEL TANK
FVO-418	FUEL FILTER (COMPLETE)
FVO-419	FUEL FILTER (INSERT ONLY)
FVO-423ATR-1	SUPPLY ELBOW C/W PICK UP TUBE - TC APPROVED TANK
2103-C-CGA	3/8" SHUT OFF VALVE
FV-431	BURNER GASKET C/W CLAMP
FV-433	FEELER GAUGE
FV-433B	FEELER GAUGE - SOLID
FV-434CB12	FRONT FACE PLATE (2 X 12") PIN LOCK/CUFF & BUCKLE
FV-434CB16	FRONT FACE PLATE (1 X 16") CUFF & BUCKLE
FV-434PL16	FRONT FACE PLATE (1 X 16") PIN-LOCK
FV-435H	OIL BURNER NOZZLE (HI ALTITUDE) (1.75 X 60W)

FV-435B	OIL BURNER NOZZLE (2.00 X 60W)
FV-437	HIGH LIMIT (150F REAR)
FV-446	SIGHT GLASS C/W FIBER GASKET
FV-447	SIGHT GLASS WASHER
FV-448	MAIN RELAY
FV-450SI	POWER INDICATOR LIGHT
FV-461	PUMP INLET/OUTLET ADAPTER
FV-471	30" 4-WIRE BX (FV SERIES)
FV-472	40" 2-WIRE BX (FV SERIES)

### TRAILER PARTS LIST

<b>Part Number</b>	<b>Part Description</b>
FV-EBK	EMERGENCY BREAKAWAY KIT
FV-403TR	205/75 R15 WHEEL AND TIRE
FVO-435TR	REPLACEMENT JACK
FVO-436TR	REPLACEMENT CHAINS
FVO-437TR	BALL HITCH
FVO-438TR	PINTLE HITCH
FVO-439TR	LICENSE PLATE LIGHT
FV-443TR	PUSH TO CLOSE DOOR LATCH
FV-444TR	LOCK DOWN LEVER LATCH - 2 PCS PER DOOR
FV-450TR	BOLT ON HINGE
FV-463TR	VENT PIPE
FV-464TR	VENT DEFLECTOR
FV-465TR	LOCKING DOOR LATCH C/W RODS
FV-466TR	15/20 AMP 2-POLE BREAKER
FMA-2312	DOOR LATCH ASSEMBLY

## GENSET/ELECTRICAL PART LIST

<b>Part Number</b>	<b>Part Description</b>
FV-440TR-1	KILL SWITCH FOR FVO-1000TR & FVO-400TR (2014>)
FV-451TR	DISTRIBUTION PANEL
FV-466TR	HEATER BREAKER -15/20 AMP 2 POLE
FV-454TR	115V GFI RECEPTACLE
FV-455TR	115V RECEPTACLE WEATHERPROOF ENCLOSURE (INCLUDES COVER)
FV-455TR-2	WEATHER PROOF CLEAR IN-USE GFI PVC COVER
FV-456TR	115V 20 AMP FEMALE PLUG END
FV-457TR	TAIL PIPE
FV-458TR	MUFFLER
FV-459TR	FLEX PIPE C/W CLAMPS FOR MUFFLER
FV-460TR	BATTERY
FV-461TR	BATTERY TRAY & HARNESS
FV-462TR	BATTERY LOCK-OFF COMPLETE
FV-474TR	YANMAR COMPLETE AIR FILTER KIT(FVO-1000TR)
FV-467TR	LOCKING DOOR LATCH C/W RODS (FVO-1000TR) HEATER INLET DOORS
FVO-424TR	COMPLETE CONTROL PANEL
FVO-425TR	10' TEMPERATURE GAUGE- FVO-1000TR
FVO-426TR	MAGNETIC SWITCH
FVO-427TR	OIL PRESSURE GAUGE
FVO-428TR	IGNITION SWITCH C/W KEYS
FVO-429TR	VOLT METER
FVO-430TR	HOUR METER
FVO-431TR	FUEL PUMP SOLENOID (YANMAR)
FVO-432TR	COOLANT SHUT-OFF
FVO-433TR	DIODE (CONNECTED TO FUEL PUMP - YANMAR MOTOR)
FVO-434TR	TIMER (YANMAR MOTOR)
FVO-444TR	BLOCK HEATER- YANMAR ENGINE (FOR FVO-1000TR)
FVO-445TR	ANTIFREEZE RESERVOIR- YANMAR ENGINE (FOR FVO-1000TR)
FVO-446TR	FAN BELT- YANMAR ENGINE (FOR FVO-1000TR)
FVO-447TR	AIR FILTER- YANMAR ENGINE (FOR FVO-1000TR)
FVO-448TR	ALTERNATOR- YANMAR ENGINE (FOR FVO-1000TR)
FVO-449TR	STARTER- YANMAR ENGINE (FOR FVO-1000TR)

FVO-450TR	SOLENOID POWER TIMER- KUBOTA ENGINE (FOR FVO-1000TR)
FVO-451TR	OIL FILTER- KUBOTA ENGINE (FOR FVO-1000TR)
FVO-452TR	FUEL FILTER- KUBOTA ENGINE (FOR FVO-1000TR)
FVO-453TR	FUEL SOLENOID- KUBOTA ENGINE (FOR FVO-1000TR)
FVO-454TR	LIFT PUMP- KUBOTA ENGINE (FOR FVO-1000TR)
FVO-454TR-G	GASKET FOR LIFT PUMP- KUBOTA ENGINE (FOR FVO-1000TR)
FVO-455TR	SLAVE SOLENOID- KUBOTA ENGINE (FOR FVO-1000TR)
FVO-456TR	FAN BELT- KUBOTA ENGINE (FOR FVO-1000TR)
FVO-457TR	AIR FILTER- KUBOTA ENGINE (FOR FVO-1000TR)
FVO-458TR	ALTERNATOR- KUBOTA ENGINE (FOR FVO-1000TR)
FVO-459TR	STARTER- KUBOTA ENGINE (FOR FVO-1000TR)
FVO-460TR	ANTIFREEZE RESERVOIR- KUBOTA ENGINE (FOR FVO-1000TR)
FVO-461TR	LOW COOLANT SWITCH- KUBOTA & YANMAR (FOR FVO-1000TR)
FVO-462TR	6.3 AMP FUSE FOR STAMFORD GENERATOR END (FOR FVO-1000TR)
FVO-463TR	STAMFORD GENERATOR END (FOR FVO-1000TR)
FVO-464TR-1	VOLTAGE REGULATOR FOR STAMFORD GENERATOR END (NEW STYLE)
FVO-465TR	UPPER RAD HOSE-YANMAR (FOR FVO-1000TR)
FVO-466TR	LOWER RAD HOSE-YANMAR (FOR FVO-1000TR)
FVO-467TR	RELAY-YANMAR (FOR FVO-1000TR)
FVO-468TR	RADIATOR-KUBOTA (FOR FVO-1000TR)
FVO-469TR	VERTICAL EXHAUST MANIFOLD-KUBOTA (FOR FVO-1000TR)
FVO-470TR	RADIATOR-YANMAR (FOR FVO-1000TR)
FVO-471TR	FAN BLADE-YANMAR (FOR FVO-1000TR)
FVO-472TR	WIRING HARNESS (FOR FVO-1000TR)
FVO-473TR	KUBOTA ENGINE (FOR FVO-1000TR)
FVO-474TR	YANMAR ENGINE (FOR FVO-1000TR)
FVO-475TR	DIODE FOR KUBOTA ENGINE (FOR FVO-1000TR)
FVO-476TR	RAD MOUNT KIT FOR YANMAR ENGINE (FOR FVO-1000TR)
FVO-477TR	FUEL PUMP FOR YANMAR ENGINE (FOR FVO-1000TR)
FVO-478TR	FUEL PUMP GASKET KIT FOR YANMAR ENGINE (FOR FVO-1000TR)
FVO-479TR	RESISTOR FOR KUBOTA ENGINE (FOR FVO-1000TR)
FVO-480TR	D1005 & D1105 KUBOTA FUEL FILTER KIT (FOR FVO-1000TR)
FVO-481TR	KUBOTA ENGINE WIRING HARNESS (FOR FVO-1000TR)
FVO-482TR	RAD MOUNTS (UPPER-YANMAR) (FOR FVO-1000TR)

<b>ACCESSORIES</b>	
FV-HD12	12" X 12-FT HITEX DUCTING PIN LOCK
FV-HD12x25	12" X 25-FT HITEX DUCTING PIN LOCK
FV-HDG16	16" X 25-FT HITEX DUCTING CUFF & BUCKLE
FV-THB	THERMOSTAT C/W 25FT CORD/MALE PLUG END
FV-THB (15M)	THERMOSTAT C/W 50FT CORD/MALE PLUG END
FVO-C7001001	EMERGENCY SERVICE KIT
FVO-C7050010	VACUUM & PRESSURE TESTER MANIFOLD